

Suggested Preventive Maintenance Schedule for Sahara Air Products Closed System Air Dryers

Service Guide



Before servicing components, it is advised that this entire Service Supplement be studied and clearly understood.

These instructions apply to the following Model of Sahara Regenerative Air Dryer:

Closed System (CS)

SAHARA AIR PRODUCTS

A Div. of HENDERSON ENGINEERING COMPANY, INC. 95 North Main Street • Sandwich IL 60548 815-786-9471 • 800-544-4379 • Fax: 815-786-6117 www.saharahenderson.com

Suggested Preventive Maintenance Schedule for Closed System Air Dryers

SUGGESTED PREVENTIVE MAINTENANCE SCHEDULE

The Closed System (CS) air dryer requires a minimum of maintenance as most components are maintenance-free; however, a certain amount of preventive maintenance is recommended to assure years of trouble-free, high performance service.

Whereas it is recommended that the dryer be observed and inspected as often as it is practical, the following is a minimum requirement.

DAILY

- 1. Check operating conditions: inlet flow, inlet pressure, temperature, and purge flow.
- 2. Check filter differential pressures.
- 3. Check dryer operating cycle.
- 4. Check outlet dew point.
- 5. Test primary drain for proper operation by pushing drain test button.

Note: Maintenance steps above can be accomplished while the dryer is operating.

EVERY 8,000 HOURS OR 12 MONTHS

- 1. Perform steps 1 through 5 as outlined in "DAILY".
- 2. If dryer has optional Dew Point Demand System:
 - a. Recalibrate or replace dew point probe/SMT. Contact Henderson Engineering Co. for instructions which will include the issue of a Return Merchandise Authorization (RMA) to send dew point equipment for recalibration to Henderson Engineering Co.
 - b. Replace inline filter for dew point sample cell.
- Test the drain trap secondary assembly and drain the sump at the separator drain of sludge that may have accumulated by closing off the primary drain until the secondary valve actuates.

Note: Maintenance steps above can be accomplished while the dryer is operating.

4. Replace filter elements.

Note: If filters are able to be isolated by themselves, dryer can continue to operate. Isolate and depressurize the filters only.

Note: For detailed maintenance procedures for replacing filter elements, contact Henderson Engineering Co. and request *Service Guide – Filter Element Replacement Instructions* (Reference SV024).

Continued on next page.

SAHARA AIR PRODUCTS

SERVICE GUIDE

Suggested Preventive Maintenance Schedule for Closed System Air Dryers

SUGGESTED PREVENTIVE MAINTENANCE SCHEDULE

EVERY 8,000 HOURS OR 12 MONTHS (continued)

- 5. Isolate and depressurize the dryer.
- 6. Disconnect power to the dryer.
- 7. Replace mufflers.
- 8. Make certain all air and electrical connections are sound. Reference the electrical torque chart which can be found inside the dryer electrical panel.
- 9. Repressurize the dryer (or filters) and place "onstream".
- 10 Reconnect power to the dryer.

EVERY 16,000 HOURS OR 24 MONTHS

1. Perform steps 1 through 7 as outlined in "EVERY 8,000 HOURS OR 12 MONTHS".



Attention / Warning!

Attention DO NOT REPRESSURIZE DRYER OR RECONNECT POWER TO THE DRYER YET!

- 2. Carefully disassemble and clean the 3-way solenoid valve on the separator drain trap.
- 3. Rebuild the secondary drain valve by installing a valve repair kit.
- 4. Disassemble and clean the primary drain.
- 5. Test desiccant for dynamic capacity. Contact Henderson Engineering Co. for instructions which will include the issue of a Return Merchandise Authorization (RMA) to send in desiccant samples for testing.
- 6. Make certain all air and electrical connections are sound. Reference the electrical torque chart which can be found inside the dryer electrical panel.
- 7. Repressurize the dryer (or filters) and place "onstream".
- 8. Reconnect power to the dryer.

SUGGESTED PREVENTIVE MAINTENANCE SCHEDULE

EVERY 24,000 HOURS OR 36 MONTHS

1. Perform steps 1 through 7 as outlined in "EVERY 8,000 HOURS OR 12 MONTHS".



Attention / Warning!

DO NOT REPRESSURIZE DRYER OR RECONNECT POWER TO THE DRYER YET!

- 2. Inspect electric heater contactor for wear and replace, if necessary. (Not applicable for steam heater.)
- 3. Grease the blower motor and bearings for all dryers 980 cfm and above.
- 4. Make certain all air and electric connections are sound. Reference the electrical torque chart which can be found inside the dryer electrical panel.
- 5. Repressurize the dryer and place "onstream".
- 6. Reconnect power to the dryer.

EVERY 32,000 HOURS OR 48 MONTHS

1. Perform steps 1 through 4 as outlined in "EVERY 16,000 HOURS OR 24 MONTHS".



Attention / Warning!

Intention DO NOT REPRESSURIZE DRYER OR RECONNECT POWER TO THE DRYER YET!

- 2. Drain all the desiccant from both vessels through the drain at the bottom of each vessel. If a handhole / manway is available, the desiccant can be removed using a vacuum truck (recommended).
- 3. Refill both vessels with the proper amount of desiccant. Reference the air dryer instruction manual for the Specifications and/or Spare Parts List which indicate the required quantity of desiccant. You can also contact Henderson Engineering for assistance; please have the S/N of the air dryer available.

Note: For detailed maintenance procedures for removing and installing desiccant, contact Henderson Engineering Co. and request *Service Guide - Desiccant Fill Instructions* (Reference SV023).

- 4. Rebuild the actuators and valves by installing repair kits in the major switching valves. If dryer has check valves, replace the check valves at this time.
- 5. Carefully disassemble and clean the solenoid valves in the control group; rebuild with new parts, only if damage or serious wear is evident.
- 6. Make certain all air, electric, and water connections are sound. Reference the electrical torque chart which can be found inside the dryer electrical panel.
- 7. Repressurize the dryer and place "onstream".
- 8. Reconnect power to the dryer.

Suggested Preventive Maintenance Schedule for Closed System Air Dryers

FIELD & TECHNICAL SUPPORT

Office: 815-786-9471 Ext. 129 Service Manager

Bryan Scott Cell: 630-697-3608 Fax: 815-786-6117

E-mail: BryanScott@saharahenderson.com

Service Engineer Office: 815-786-9471 Ext. 127

Andres Perdomo Fax: 815-786-6117

E-mail: AndresPerdomo@saharahenderson.com

INSIDE SALES FOR PARTS

Inside Parts Sales Phone: 815-786-9471 Ext. 134

Mimoza Jaisi Fax: 815-786-6117

E-mail: Sales@saharahenderson.com

When contacting Henderson Engineering, please have the following information available:

- **Serial Number** which can be found on the air dryer; either on the ASME code nameplate on the dryer towers or in the electrical enclosure.
- **Model Number** which can be found on the air dryer; either on the ASME code nameplate on the dryer towers or in the electrical enclosure.
- Inlet air temperature and pressure.
- Actual inlet flow rate.



Henderson Engineering Co., Inc., is proud to be certified to the **ISO 9001 Quality Management System** standards and guidelines.

Sahara Air Products, Div. of Henderson Engineering Co., Inc.

www.saharahenderson.com

Phone: 815-786-9471 • Fax: 815-786-6117

Business Office Hours: Monday - Friday 8:00 a.m. - 4:30 p.m. Receiving Dock Hours: Monday - Thursday 7:30 a.m. - 3:30 p.m.

Copyright © 2023 Henderson Engineering Co., Inc. All rights reserved.

Information contained in this Service Supplement was in effect at the time of publication and is subject to change without notice or liability. Henderson Engineering Co., Inc., reserves the right to revise the information presented herein at any time.